


# HI-STANDARD REVOLVER WESTERN-STYLE



## PARTS PRICE LIST-.22 CALIBER MODEL W-104 "DOUBLE-NINE"

NUMBERS ARE ONLY FOR BLUED GUNS - SEE PARTS LIST FOR NICKEL



## HI-STANDARD

#### .22 CALIBER DOUBLE- AND SINGLE- ACTION REVOLVER

#### PARTS LIST AND PRICES

(Prices Subject to Change Without Natice)

### "DOUBLE-NINE"

#### MODELS W-104 BLUED AND NICKEL

#### HOW TO ORDER REPAIR PARTS

The following information must be furnished when aidering replacement parts:

- 1. Model Name and Series Number W-104
- 2. Serial Number
- 3. Number and Name of Paris
- 4. Color

#### MINIMUM ORDER \$1.00

A minimum charge of \$1.00 is made on all orders where the normal cost would be less than \$1.00. Please note also the following paragraph. Additional parts will be added to meet the minimum charge.

#### PAYMENT

All posts shipments will be made by Parcel Post C.O.D. unless advance remillance is made. PLEASE DO NOT SEND CASH OR STAMPS. Checks, Money Orders, or Oralls are acceptable and will save you C.O.D. charges.

#### FACTORY SERVICE

Il poils ore to be filled at the loctory, send revolver marked lai the attention of our SERVICE DEPARTMENT, furnishing complete and specific repoir instructions. A rost estimate of the parts and labor rharges will be immediately sent for your approval before work is started.

Unless a flat rate charge is specified, a MINIMUM of \$6.50 will be charged an servicing revolver at the factory.

#### REVOLVER SHIPPING INSTRUCTIONS

BONAFIDE DEALERS IN FIREARMS are permitted by postal regulations to send revalvers to the factory by Pairel Post. INDIVIDUALS are not permitted to mail firearms and we recommend shipment by railway express.

All shipments to foctory must be prepaid.

#### MODEL W-104

Pail Number	Parl Name	Price				
Parts Marked With An Asterisk (*) Must Be Filled at the Factory						
*7360	Barrel (51/2") Blue, (Without Sight)	\$ 8.00				
*7460	Borrel (51/211) Nirkel, (Without Sight)	9.00				
*7515	Barrel & Front Sight Assembly, Blue (includes Barrel 7360, Frant Sight 7562)	8.50				
*7494	Berrel & Frant Sight Assembly, Nickel (includes Barrel 7460, Frant Sight 7562)	9.50				
7104	Barrel Pin, Blue	.25				
7196	Barrel Pin, Nirkel	.40				
7506	Crane Assembly, Blue (includes Crane Link 7505, Crane Link Bearing 7107)	3.00				
7406	Crone Assembly, Nirkel (includes Crone Link 7407, Crone Link Bearing 7107)	3.85				
7508	Cylinder, (Not Sold Separately, See Cylinder Assembly)					
7670	Cylinder Assembly, Blue, (Includes Ejerlor 7580, Ejeclor Alignment Dewel 7117, Cylinder Lock Plunger 7575, Cylinder Lock Plunger Pln 7112, Cylinder Lock Plunger Spring 7513, Cylinder Ejertor Alignment Pin 7245, Ejeclor Rod 7510, Ejeclor Returo Spring 7576, Retaining Ring 7577, Return Spring Washer 7578, Crona Link Assembly 7596, Cylinder 7508, Cylinder Bushing 7110)	16.50				
7423	Cylinder Assembly, Nirkel, (Inriudes Ejector 7590, Ejector Alignment Dawel 7117, Cylinder Lock Plunger 7575, Cylinder Lock Plunger Pin 7112,	18.50				

#### MODEL W-104

Pori Number	Parl Name		
	Cylinder Lork Plunger Spring 7513, Cylinder Ejector Alignment Pin 7245, Ejertor Rod 7410, Ejector Rod Relum Spring Washer 7578, Ejector Rod Return Spring 7576, Retaining Ring 7577, Crane Link Assembly 7406, Cylinder 7508, Cylinder 8ushing 7110)		
7575	Cylinder Lock Plunger	.63	
7112	Cylinder Lork Plunger Pin	.2.	
7513	Cylinder Lock Plunger Spring	.2	
7162	Cylinder Stop Assembly, (Includes Cylinder Stop 7114, Cylinder Stop Cross Pin 7115)	1.8	
7158	Cylinder Stop Spring	.2	
7245 7580	Cylinder Ejertor Alignment pin Ejector, (Not sold Separately, See Cylinder Assembly)	.2	
7117	Sierlor Alignment Dowell	.5	
+ 7581	Ejecter Assembly (net said separately)	1.0	
7522	Ejerjai Lairh Mousing, Slue	7.0	
7422	Ejerlar kolin Housing, Nirkel	2.6	
7526	Ejector Latch Housing Strew, Blue		
7476	Elector Lotch Housing Screw, Nickel		
7529		1.	


Part Number	Pari Naine	Prire	Port Number	Part Name	Priro
7429	Ejertar Latch Rod Assembly, Nickel (includes Latch Rod 7521, Latch Thumb Piece 7525, Latch Hook 7524,	2.50			
7527	Ejector Latch Housing Plug, Stue	.35			
7427	Ejector Latch Housing Plug, Nickel	.49	7534	Hammer Pivot Screw, Blue	25
					.25
7528	Ejertor Latch Rod Spring	.25	7434 7134	Hammer Pivot Screw, Nickel	.25
7576	Ejertor Rod Return Spring	.25	7182	Hommer Sefety Stop Hommer Steave	.25 .25
730)	Esculchean Nul	.25	7335	Hammer Spring	.25
			7354	Hommer Spring Guide Head Assembly (includes	1.65
×7337	Frame, Blue (Not Sold Separately)		7004	Hammer Spring Guide Head 7336, Hammer Spring Guide Pin 7137)	1.03
• 7437	Frame, Nickel (Not Sold Separately)				
<b>7</b> 510	Ejerter Rad, Blue	1.25			
7410	Ejertar Rod, Nirkel	1.50	7574	Hond	1.25
		7.00	718t	Hand Spring	.25
†7 <i>5</i> 30	Grip Assembly, R.H., Ivory (includes Medallian 10355)	2.00	7140	Link Pivot Pin Medallian, Blue	.25
	100007		†0355 10356	Medallian, Nickel	.65
17531	Grip Assembly, L.H., Ivary (includes Madallian	2.00	7577	Retaining Ring	.65 ,25
	10355)		7578	Return Spring Washer	.25
17327	Grip Assembly, R.H., Block (includes Medallion	2.00	7562	Sight, Front	1.10
13 421	10356)		7444	Sight, Rear	t.35
		4.00	7382	Trigger	2.50
7328	Grip Assembly, L.H., Black (includes Medaltion 10356	2.00	7384	Trigger and Trigger Spring Contact Pin 7130	2.75
7313	Grip Screw	.25		Assembly	2., 0
7324	Grip Alignment Pin	.25	7339	Trigger Guard, Blue	5.00
7386	Hammer	4.50	7439	Trigger Guard, Nickal	5.50
7388	Hammer Assambly, (includes Hammer 7386,	5,50	7149	Trigger Pivot Pin	.25
, 000	Hammer Pawl 7129, Pin 7130, Spring 7131)		738†	Trigger Spring	.25
7129	Hammer Powl	t.25	7149	Trigger Spring Rataining Pin	.25
7130	Hammer Pawt Pin	.25	7540	Trigger Guard Assembly Pin, 8lve	.25
713t	Hammer Pawl Spring	.25	7440	Trigger Guard Assembly Pin, Nirkel	,25
	† Grips sold only in matching pairs		7130	Trigger Spring Contact Pin	.25

## INSTRUCTIONS FOR OPERATION AND CARE OF YOUR "OOUBLE-NINE" REVOLVER

#### LOADING AND FIRING:

- 1. Be sure that hommer is forward.
- 2. Hold Revolver in right hand with Index finger of left hand against front of ejector latch housing. With left thumb move ejector latch to extreme forward position and, at the same time, swing out cylinder to left by pressing right Index finger against II (See Figure 1). Be sure to release ejector latch
- Insert one .22 coliber short, long or long rifle cartridge in each of the nine chambers of the cylinder.
- 4. Return cylinder to frome by pressing thumb against cylinder. Do not push ejector lotch forward when closing cylinder. The revolver is now ready to fire.
- Revolver may be fired double action merely by squeezing trigger for each shot.
- Torget shooting, or other shooting demonding a maximum of occuracy, is usually done single action. For single-action shooting, pull back hommer to cocked position for each shot.
- 7. To unfood revolver or remove fired cortridge coses, move ejector lotch to extreme forward position and at the same time, swing out cylinder to left by pressing right index finger against it (See Figure 1), and push ejector rad to the rear (See Figure 2).
- 8. Spring loaded ejector will return outomotically to forward position.
- Because cylinder chambers are counterbored, revolver may be "dry-fired" without injury to cylinder.

Double-Nine revolvers are sighted in at a range of 50 feet. If lateral adjustment is desired because of individual preference in sighting or holding, top the reor sight gently, using a bross or plostic hammer. Move the rear sight in the direction you want the paint of impact to move,



#### CARE AND CLEANING DOUBLE NINE

1. If, ofter extensive shooting, cleoning becomes necessory, the use of kerosene or any other good quality cleoning solution is recommended.

- In cleaning the face of the cylinder or muzzle, on old toothbrush or similar brush should be used.
   Unless mud or foreign matter enters the bare, it
- should be cleaned very sparingly. If cleaning becomes necessary, a stiff bristle brush or copper wire brush for .22 caliber guns should be used. After brushing, the bore should be swobbed with flonnel potches attached to a .22 caliber cleaning rod (patches should be moistened with a good quality gun all). The swobbing of the bore should be continued until the patches come out clean. IT IS STRONGLY EMPHASIZED THAT THE BORE RARELY REQUIRES CLEANING EXCEPT FOR THE PRESENCE OF MUD OR FOREIGN MATTER.
- In cleaning the cylinders of the revolver, the same procedure as used in the cleaning of the bare should be employed.
- The entire gun should be wiped dry of kerosene or cleoning solution with a cleon obsorbent cloth and then the surfaces should be wiped with a lightly ailed patch.
- 5. For best results in rust prevention only gun oils contoining silicon should be used.
- 6. A few drops of light-bodied oil should be applied to the action internally near the pivot point of the hammer. Retract the hammer first then work the trigger double action a few times to distribute the oil. The same procedure applies to the cylinder crane link and the ejector latch slot in the housing offixed to the barrel.
- 7. Avoid using heavy-bodied oils. No animal or vegetable oils should ever be used in guns.
- 8. If the gun is used in climates where extreme cold prevaits, powdered graphite should be substituted for oil in lubricaling the internal mechanism. In moist climates the gun should be cleaned more frequently and preferably stored in a container treated with silicanes to prevent rust.

## Hi-Standard .22 Caliber Autoloading Pistols

### ALL-STEEL FIELD MODELS



**Sport-King:** Favorite .22 long rifle autolooder boasts remarkable engineering odvances and wonder metals for top performance in the field. Ideal handgun for hunters, trappers, campers, fishermen, plinkers, target shaoters.

Flite-King: Same outstanding features as Spart-King, but fires thrifty, quiet .22 shorts.



**Dura-Matic:** The perfect extra gan at a low price. Fires .22 long rifle ammunition with excellent accuracy. Dauble safety has a visible indicator to show when gun is ready to fire, plus a combination slide lack far positive cross-bolt safety. This versatile 10-shot autolaader fits the need of many shooters who can take pride in its sleek, modern lines.

## LIGHTWEIGHT FIELD MODEL



Sport-King Lightweight: High tensile metals used in missiles are crafted into forged-alloy frames for these amazing handgurs. Light in weight for easy carrying, you get tremendous durability for a lifetime of shaoting fun. Spart-King Lightweight is a ten-shat .22 long rifle autoloader available in blued finish.

## SUPER-ACCURATE TARGET MODELS



Supermatic Trophy: A possession of pride worthy of the world's greatest champians. Superb hand-finishing inside and out for unexcelled beauty and precision performance. Tenshot .22 L.R. autoloader has gald trigger and lettering, walnut grips.

Supermatic Citation: All the features of Trophy with Citation-grade finish, laminated grips.

Olympic: 22 shart version of this superb target-grade handgun.



Supermotic Tournoment: Top value in a medium-priced target pistal. Full measure of Hi-Standard quolity with all but a few of the custom extras faund in the Trophy. Choice of 4½" at 6¾" heavy, tapered, interchangeable barrels. Doubleaction sofety. Sure-fire magazine. Diamond-checkered laminated grips.